

## **Multi-sockets Square Li-ion Battery**

PB-S series camera batteries are compact designed, shorter than normal V/Gold mount batteries, and match perfectly with most of the Cine-cameras. The build-in LCD can display accurate power info during charging and discharging, and support viewfinder info display on both SONY and RED cameras. To make convenient connections, the PB-S batteries provide USB output socket and up to 4 D-tap sockets for camera-top devices.













## PB-S220A/S 220Wh

- Square shape design for Cine-cameras
- Max 150W, 12A high load
- ◆ 4× D-tap output sockets (Max 120W/10A in total)
- ◆ 1× USB 5V/2A power output sockets
- 6A fast charging by charger S-3812S
- LCD display accurate remaining run time
- Display power info in both SONY & RED
- Multiple circuit protections

PB-S220A: Gold mount PB-S220S: V-mount

Model		PB-S220S	PB-S220A
Model		PB-32203	PD-3220A
Battery plate		V-mount	Gold-mount
Nominal voltage		14.4V	14.4V
Capacity		220Wh,15.3Ah	220Wh,15.3Ah
Max output	Electrodes	150W,12A	150W,12A
	D-TAP	120W,10A	120W,10A
	USB	10W,5V/2A	10W,5V/2A
	In total	150W	150W
Dimension		121×95×96mm	121×95×99mm
Net weight		1.44kg	1.435kg
Max charging current		6A	6A
D-TAP socket number		4	4
USB socket number		1	1



Power info display – The LCD displays remaining power percentage, remaining working time, low power warning, and battery cycle times.



Display power percentage when the battery is free or during charging.



Display remaining running time when the battery is powering on camera or any devices. Press power check button can switch to power percentage display.



When remaining running time is less than 15 minutes, the LCD will flash to remind changing battery.



Long press power check button for 5 seconds, it will display battery cycle times.



Display warning info when the battery detected over discharging, over charging current / voltage, over load, short circuit, etc. Refer the warning code to User Manual to take steps.