

SWIT®**DB-F570**

NP-F type USB-C Dummy Battery

Ver:A

USER MANUAL

SWIT Electronics Co.,Ltd.

Tel:+86-25-85805753
Fax:+86-25-85805296
<http://www.swit.cc>
E-mail: contact@swit.cc

Congratulations on your purchase of this product. Please read this user manual carefully

Warning & Caution

- Use the product in a dry and well-ventilated environment, avoid rain and moisture.
- Ensure the firm connection between the product and camera, as well as external power supply.
- Do not attempt to disassemble the product to prevent internal circuit damage.
- Use the product at normal temperature, avoid extreme high and low temperature environment.
- Check the product appearance before use, do not use the damaged one.

Product Brief

DB-F570 is the NP-F type dummy battery with USB-C port, allows you to power SONY ENG cameras, and all 3rd party cameras and video devices that use NP-F battery, by external USB-C power source.




Fig.1 DB-F570

Features

- USB-C PD Power Input
- NP-F type Pins 8.4V(Reg.) 3A output
- For SONY ENG cameras with NP-F plate
- For BMPPC 6KG2/6KPRO
- For ZCAM E2/E2-M4/S6/S6G/F6/F8
- For any Video Devices with NP-F plate
- Display power info in SONY viewfinder
- Cable length 50cm

Specification

Model	DB-F570
Battery pins output	8.4V(Reg.),3A
Compatible Cameras	SONY HXR-NX100/200, HXR5R/NX3; SONY HXR-MC2500; SONY HDR-FX1000/1000E, AX2000; BMD BMPCC 6KPRO/6KG2; ZCAM E2/E2-M4,E2-S6/S6G,E2-F6/F8 and all video devices with NP-F plate
Cable Length	50cm